

SERVICE PARTS LIST PPS220

Parts No	Description
2	Left saucer
3	Left outer burner cap
4	Left inner burner cap
5	Trivet
7	2# Burner
8	Left gas valve
10	1# Gas tube
11	Right gas valve
12	1# Burner
13	Knob
14	Knob seat
17	Right outer burner cap
18	Right inner burner cap
19	Right Saucer
25	Stove foot

